




TRANSHOW SCREW FACTORY

GAOYANG RD, ZHOUEAN VILLAGE, JIANGSHAN TOWN
 YINZHOU DISTRICT, NINGBO CITY, 315100 CHINA
 Tel: +86-574-8736.7873 Fax: +86-574-8736.4349
www.transhow.net Email: transhow@transhow.net

DIN 6928 Hex Washer Head Self Tapping Screws



		2,2	2,9	3,5	3,9	4,2	4,8	5,5	6,3
D	min	2,10	2,79	3,43	3,78	4,09	4,65	5,31	6,10
	max	2,24	2,90	3,53	3,91	4,22	4,80	5,46	6,25
B	min		6,02	6,61	8,46	8,10	9,80	10,00	12,20
	max		6,50	7,21	9,18	8,80	10,50	11,00	13,50
A	min		4,82	5,32	6,78	6,78	7,78	7,78	9,78
	max		5,00	5,50	7,00	7,00	8,00	8,00	10,00
H+U	min		1,62	2,74	2,42	3,60	3,80	4,80	5,30
	max		1,87	2,99	2,67	4,10	4,30	5,30	5,90